

## PROVISIONS ΒY OTHERS

\*GENERAL\_ HE HOISTVAY MUST BE IN ACCORDANCE WITH SAFETY CODE FOR ELEVATORS (ASME A17.1 OR B44-2000) AND ALL STATE/PROVINCIAL AND LOCAL CODES.

PLUMB HIDISTYAY— DIE TO CLOSE RUNNING CLEARANCES DWNER/AGENT MUST ENSURE THAT HIDISTWAY AND PIT (WHERE PROTVIDED) ARE LEYEL, PLUMB AND SQUARE AND ARE IN ACCORDANCE WITH THE DIMENSIONS ON THESE DRAWINGS.

<u>MINIMUM OVERHEAD CLEARANCE</u> OWNER/AGENT MUST ENSURE MINIMUM OVERHEAD CLEARANCE IS IN COMPLIANCE WITH CODES.

CONSTRUCTION SITE— DYNER/AGENT TO PROVIDE ALL MASDARY,
CAPPENITRY AND DRYMALL VIDEX AS REQUIRED AND SHALL PATICH AN
MAKE GIOD CINCLUDING FINISH PAINTING) ALL AREAS WHERE
IN WALLS/FLDIRS MAY REQUIRE TO BE CUT, DRILLED DR ALTERED IN
ANY VAY TO PERMIT THE PROPER INSTALLATION OF THE LIFT. PATCH AND

DIMENSIONS
CONTRACTOR/COUSTOMER TO VERIFY ALL DIMENSIONS AND REPORT ANY DISCREPANCIES TO OUR OFFICE IMMEDIATELY.

\*STRUCTURAL\_

ELOBACUPPORT WALL LIADIS— STRUCTURAL ENGINEER TO ASSURE THAT BUILDING AND SHAFT WILL SAFELY SUPPORT ALL CIADIS IMPOSED BY THE LIFT EQUIPMENT, REFER TO THE TABLES ON THIS DRAWING FOR LOADS IMPOSED BY THE EQUIPMENT.

<u>DOORS-</u> SUITABLE LINTELS MUST BE PROVIDED BY OWNER/AGENT DOOR FRAMES ARE NOT DESIGNED TO SUPPORT OVERHEAD WALL

DEATION / ACCESS— MACHINE ROIM LICATED AT THE LIVEST EVEL ADLACENT TO HISTONAY, UNLESS SHOWN OTHERVISE IN THE AYOUT DRAVINGS, FIELD ADJUSTMENT BY INSTALLER MAY BE RECESSARY TO MEET JOB SITE CONDITIONS OR REGULATIONS, ACCESS OF THE PROPERTY OF MACHINE, ROIM TO BE THROUGH A SELF CLOSING AND SELF ACCESS

<u>SLEYVES FOR DIL & ELECTRIC LINES- PROVIDED BY OTHERS, FROM MACHINE ROOM TO HOISTWAY. GPOSITION PER INSTALLERS INSTRUCTIONS).</u>

IGHTS		INFO	
115/1PH	230/1PH/60HTZ	208/3PH/60HTZ	INPUT VOLTAGE (V/PH/CYCLE)
	60	30	DISCONNECT SIZE (AMPS)
15	50	30	TIME DELAY   FULL LOAD   FUSE (AMPS)   CURRENT (
	21	15.6	DISCONNECT   TIME DELAY   FULL LOAD   SIZE (AMPS)   FUSE (AMPS)   CURRENT (AMPS)
	115/1PH	230/1PH/60HTZ 60 50 50 15/1PH 15	208/3PH/60HTZ 30 30 230 230/1PH/60HTZ 60 50 50 115/1PH 15

POWER SUPPLY— (SEE SPECIFICATIONS) LOCKABLE FUSED DISCONNECT WITH AUXILLARY CONTACT TO BRAKE THE BATTERY FEED, OR CIRCUIT BREAKERS VITH A 3-POLE BREAKER FOR BATTERY FEED REQUIRED, IN COMPLIANCE WITH ELECTRICAL CODE, AS FOLLOWS (LOCATED ON WALL ON LOCK JAMB SIDE OF MACHINE ROOM DOOR)

<u>LIGHTING-</u> DWNER/AGENT TO ENSURE AT LEAST 5 FTC OR 54 LUX AMBIENT LIGHTING OVER ELEVATOR AREA.

EASCIA PANEL BELDY UPPER LEYEL ENTRANCE- WHERE REGUIRED, FASCIA PANEL MUST BE FASTENED TO A SOLID VALL AND BE PERPENDICULAR TO THE FLOOR AND VALLS. HOISTVAY FASCIA IS NOT SELF-SUPPIRITING FOR LING, CONTINUOUS RUNS VOID OF ENTRANCES, ADEQUATE SUPPORT AND THE FASCIA MUST BE PROVIDED BY OTHERS.

RETURN WALLS\_ RETURN VALLS AT ENTRANCES MUST BE BUILT-IN BY OTHERS AFTER ENTRANCE ASSEMBLIES ARE IN PLACE. ENTRANCE ASSEMBLY MUST BE SECURELY FASTENED TO VALLS BY ELEVATOR CONTRACTOR. ENTRANCE ASSEMBLIES— ENTRANCE ASSEMBLIES MUST BE ADJUSTED TO ALIGN WITH PLATFORM AND INTERLOCK EQUIPMENT. OTHERS TO ALLOV AN ADEQUATE ROUGH OPENING.

REV-000

ORION MODEL 5151